g		GE Energy	Functio	onal Te	esting Spe	cification		
Parts & Repair Services Louisville, KY				LOU-GED-IS200ERRR				
		e for a card tested in the G	eneva Test System a	nd in a	EX2100 Pan	el		
	DOCUMENT REVISION STATUS: Determined by the last entry in the "REV" and "DATE" column							
REV.		DESCRIPTION			SNATURE	REV. DATE		
Α	Initial release			Da	n Waddy	4/10/2018		
В								
С								
Hard co	YRIGHT GENERAL ELECTI pies are uncontrolled and are f		RIETARY INFORMATION (DF GENER	RAL ELECTRIC C	COMPANY AND		
	ARED BY	ED TO OTHERS, EXCEPT WITH THE	REVIEWED BY	r GENEK	QUALITY APP L. GROVES	ROVAL		
DATE 4-10-2		DATE	DATE		DATE 4-18-2018			

LOU- GED-IS200ERRR	g GE Energy	Page 2 of 3
	Parts & Repair Services	. age = 0. c
REV. A		
	Louisville, KY	

1. SCOPE

1.1 This is a functional testing procedure for a Card.

2. STANDARDS OF QUALITY

2.1 Refer to the current revision of the IPC-A-610 standard for workmanship standards.

3. APPLICABLE DOCUMENTS

- **3.1** The following document(s) shall form part of this specification to the extent specified herein. Unless otherwise indicated, the latest issue shall apply.
 - **3.1.1** Check board's electronic folder for more information

4. **ENGINEERING REQUIREMENTS**

- 4.1 Equipment Cleaning
 - **4.1.1** Equipment should be clean and free of debris prior to applying power unless performing an initial check. Refer to site specific SRA's for cleaning guidelines.
- **4.2** Equipment Inspection
 - **4.2.1** Equipment should be visually inspected for any defects prior to applying power. This inspection should include the following as a minimum:
 - 4.2.1.1 Wires broken, cracked, or loosely connected
 - 4.2.1.2 Terminal strips / connectors broken or cracked
 - 4.2.1.3 Components visually damaged
 - **4.2.1.4** Capacitors bloated or leaking
 - 4.2.1.5 Solder joints damaged or cold
 - 4.2.1.6 Circuit board burned or de-laminated
 - 4.2.1.7 Printed wire runs / Traces burned or damaged

5. EQUIPMENT REQUIRED

5.1 The following equipment is required to perform the process requirements. Equipment may be substituted provided that all accuracy's and test ratios are equivalent or better.

Qty	Reference #	Description
1	H188912	GenRad GR2000 "Geneva" system
1		ERRR Geneva Test Fixture
1	H190128	EX2100 Cabinet

LOU- GED-IS200ERRR
REV. A

GE Energy
Parts & Repair Services
Louisville, KY

Page 3 of 3

6. <u>Testing Process</u>

- 6.1 Setup
 - **6.1.1** Install fixture (on loan from Salem) onto Geneva test System.
 - **6.1.2** Install UUT into test fixture.
- **6.2** Testing Procedure
 - **6.2.1** Load ERRR_Louisville test program and follow instructions on screen.
- 6.3 EX2100 Cabinet Testing Procedure
 - **6.3.1** Power off the cabinet.
 - 6.3.2 Remove test card and install customer card into desired rack. (There are several cables that connect to the ERRR, be careful not to damage any connectors when removing or installing the card into the slot.)
 - **6.3.3** Apply power to the cabinet and go online on Toolbox.
 - 6.3.4 Verify that all trips and alarms clear and that the status is a green CONTROL/EQUAL at the bottom right corner. (If the status is not "CONTROL/EQUAL" it may be necessary to perform ACL downloads. To do so go to the DEVICE dropdown, select Download to ACL, select runtime and follow prompts, follow the same steps and select application code, cycle power, once the cabinet has rebooted perform a check/ build/ download.)
 - **6.3.5** Allow card to burn-in for 12 Hrs..
- 6.4 Post Testing Burn-in Required X Yes No
- 6.5 ***TEST COMPLETE ***
- 7. Notes
 - 7.1 None at this time?
- 8. Attachments
 - **8.1** None at this time?